

LED Pattern Quick Guide

Kvaser Leaf Light HS V2













Kvaser Leaf V3



LED Pattern Quick Guide

Kvaser Leaf Light HS V2

Kvaser Leaf V3

Pattern	Status	Description
   Steady green light	Normal (Good)	Steady (solid) green indicating the unit is powered on and working properly.
   1 sec. 2 sec.	Not Connected	Blinking green once every three seconds indicates the unit is not communicating with the PC driver. This could be caused by the driver not being installed or incompatible.
   1/4 sec. 1/4 sec.	Configuration Issue	Blinks green twice every second indicating an issue with the unit's firmware or configuration.
   Blinks yellow	CAN Activity	Lights up yellow when a CAN frame is transmitted or received on the bus.